Guide only

Before Starting

- 1. Read and understand the Hazard Assessment sheet.
- 2. Do not use extension leads longer than 20 metres.

Chainsaws are very dangerous pieces of equipment when not used properly. Always take care when using a chainsaw. Operators should not perform duties beyond their capabilities.

Replacing the chain

- 1. Loosen the Chain tensioner screw.
- 2. Undo the chain assembly cover on side of machine
- 3. Remove Chain and bar
- 4. Mount new chain on bar, taking care to place chain on, in the right direction. Put chain and bar, back onto chainsaw.
- 5. Place cover back on and put nuts holding cover on finger tight
- 6. Adjust the chain tensioner screw, so the chain is at the correct tension.
- 7. Tighten the nuts that hold the cover on.

To Start the Engine - Petrol models.

- 1. While holding both throttle triggers in, position the switch in the 'choke' position, (the bottom most switch). This should hold the throttle in.
- 2. Crank the pull cord, until the engine 'coughs'.
- 3. Flick the switch up one position and then crank the pull cord until the engine starts.

Trouble Shooting

Problem	Possible Solution

Mandatory Personal Protective Equipment:











Dust Mask

Foot Protection

Hearing Protection

Goggles

Protective Safety Clothing

Do not under any circumstances attempt any repairs. Call your local HireDepot office.

This operating and safety brochure is intended as a guide only. It does not override license requirements nor is it suitable as an operating lesson.

If you are unsure about any aspect of the equipment, its capabilities or the correct usage, please call our trained staff for instruction or any questions you may have regarding the safe operation of this equipment.