

Chain trencher

(Guide only)

BEFORE STARTING (VERY IMPORTANT)

- 1. Ensure there are no pipes in the area where you are to dig. DIAL 1100 BEFORE YOU DIG. Failure to locate and avoid electric cables and gas pipes could result in death.
- 2. If the trencher hits a solid object, release the throttle immediately and raise the bar.
- 2. Read and understand the hazard assessment sheet.

TO START THE ENGINE

- 1. Move ignition switch to the 'on' position.
- 2. Set the throttle to the half throttle position.
- 3. If the engine is cold, turn the choke lever to the 'on' position.
- 4. Turn the fuel tap on.
- 5. Crank the pull cord, until the engine starts.
- 6. Once the engine is running turn the choke off.

TO STOP THE ENGINE

- 1. Raise the bar out of the ground.
- 2. Release the throttle.
- 3. Turn the ignition switch to the 'OFF' position / depress the off button.

OPERATING PROCEDURE

HAIN TRENCHER

- 1. Firmly grip both handles during operation to maintain control.
- 2. Position the machine to work backwards.
- 3. Increase the throttle speed to the desired location, and slowly lower the bar until the desired depth is reached.
- 4. Place the handle in the operating postition.

TROUBLESHOOTING		
Problem	Possible solution	
Chain has displaced from bar.	Call your local Hiredepot branch for further instruction.	

SPECIFICATIONS		
Trench width	75mm	
Trench depth	Adjustable to 600mm	
Weight	180kg	
Dimensions		
Length	2200mm	
Width	760mm	
Height	950mm	
Transport	Trailer, utility vehicle	

MANDATORY PERSONAL PROTECTIVE EQUIPMENT







Do not under any circumstances attempt any repairs. Please call your local Hiredepot branch for assistance.

This operating and safety brochure is intended as a guide only for the safe operation of this equipment. It does not override license requirements nor is it a substitute for structured operating lesson. If you are unsure about any aspect of the equipment, its capabilities or the correct usage, please call our trained staff for instruction or any questions you may have regarding the safe operation of this equipment.

When service matters. **hiredepot.com.au**

GLEN IRIS

70 High St 9885 4431

FAIRFIELD

323 Darebin Rd 9499 9955