

## Concrete mixer (electric / petrol)

(Guide only)

### BEFORE STARTING (VERY IMPORTANT)

1. Read and understand the hazard assessment sheet.
2. Do not use extension leads longer than 20 metres.

### SETUP (ELECTRIC MODELS)

1. Lay the mixer on the ground, so that the mixer is resting on its wheels and the handles.
2. Connect the legs together using the drop bar and pin provided.
3. Place the legs inside the bottom of the machine, whilst the machine is laying down.
4. Rotate the machine upwards by lifting it from the handles.

### TO START THE ENGINE (PETROL MODELS)

1. Move ignition switch to the 'on' position.
2. Set the throttle to the half throttle position.
3. If the engine is cold, turn the choke lever to the 'on' position.
4. Turn the fuel tap on.
5. Crank the pull cord, until the engine starts.
6. Once the engine is running turn the choke off.

### PACKUP

1. Each time machine is stopped, clean mixer by placing a couple of half bricks into mixer with water and run for 5 mins. Empty contents out.

### MANDATORY PERSONAL PROTECTIVE EQUIPMENT



### TROUBLESHOOTING

Problem	Possible solution

**Do not under any circumstances attempt any repairs. Please call your local Hiredepot branch for assistance.**

This operating and safety brochure is intended as a guide only for the safe operation of this equipment. It does not override license requirements nor is it a substitute for structured operating lesson. If you are unsure about any aspect of the equipment, its capabilities or the correct usage, please call our trained staff for instruction or any questions you may have regarding the safe operation of this equipment.