

## Genie hoist

### Before use:

- Persons using this machine must be a licensed or competent experienced operator.
- Read the hazard assessment sheet.
- Ensure area is suitable for machine operation and no bystanders are present.
- Ensure the working area is clear of obstructions, powerlines and all other hazards.

---

### OPERATING PROCEDURE

#### Do not operate unless:

You learn and practice the principles of safe machine operation and read the hazard assessment sheet.

1. Avoid hazardous situations.
2. Always perform a pre-operation inspection.
3. Always perform function tests prior to use.
4. Inspect the workplace.
5. Only use the machine as it was intended.

---

### SETUP

Select an area that is firm, level and free of obstructions.

1. Remove the travel locking brake, by first releasing the tension in the cable.
2. Lower the stabilising legs where provided, and ensure they are locked into position.

---

### RAISING AND LOWERING THE LOAD

1. Centre the load on the load handling attachment. Do not overload.
2. Make sure the load is properly secured.
3. Raise the load by firmly grasping the winch handles and rotating them toward the mast.
4. To lower the load, firmly grasp the winch handles and rotate them away from the mast.

---

### PACKUP (VERY IMPORTANT)

1. Lower the mast.
2. Apply the transport brake, and raise the mast until there is tension on the cable. Failure to do so can result in the cable dislodging from the pulleys. This will result in a very costly repair bill.

Note: This operating and safety brochure is intended as a guide only. It does not override license requirements nor is it suitable as an operating lesson. If you are unsure about any aspect of the equipment, its capabilities or the correct usage, please call our trained staff for instruction or any questions you may have regarding the safe operation of this equipment.