

# Operating Procedure

# Wacker Rammer

Guide only

### Before Starting

1. Read and understand the Hazard Assessment sheet.

### To start the Engine

1. Move ignition switch to the 'on' position.
2. Set the throttle to the half throttle position.
3. If the engine is cold, turn the choke lever to the 'on' position.
4. Turn the fuel tap on.
5. Crank the pull cord, until the engine starts.
6. Once the engine is running turn the choke off.

### To stop the Engine

1. Release the throttle to the idle position
2. Allow the engine to cool at idle for 1 min.
3. Place the idle control in the off position.
4. Turn the fuel tap off.

### Operating Procedure

1. To begin operation, bring the idle up to operating speed and this will automatically engage the clutch.
2. Firmly grip both handles during operation to maintain control.

### Specifications:

Weight: 70kg  
Length: 680mm  
Height: 970mm  
Width: 350mm  
Power: 2 stroke petrol.

Transport: Trailer, Utility vehicle.

## Trouble Shooting

Problem	Possible Solution

### Mandatory Personal Protective Equipment:



Dust Mask Protection



Foot Protection



Hearing



Goggles Clothing



Protective Safety

**Do not under any circumstances attempt any repairs. Call your local HireDepot office.**

This operating and safety brochure is intended as a guide only. It does not override license requirements nor is it suitable as an operating lesson.

If you are unsure about any aspect of the equipment, its capabilities or the correct usage, please call our trained staff for instruction or any questions you may have regarding the safe operation of this equipment.