

Pressure washer

(Guide only)

BEFORE STARTING (VERY IMPORTANT)

1. Read the hazard assessment sheet.
2. The machine should be operated in the upright position. The machine should be resting on all four wheels.

PLEASE NOTE: FAILURE TO HAVE THE MACHINE IN THE CORRECT POSITION WILL CAUSE MAJOR DAMAGE TO THE MACHINE. THE PERSON RESPONSIBLE FOR HIRING THE MACHINE WILL BE LIABLE.

OPERATION

1. Ensure the machine is in the upright position (see above).
2. Connect the inlet and outlet hoses to the machine.
3. Start the motor.
4. Do not leave the machine running without constant water running through the machine. If you are not using the water jet for a period longer than 10-20 seconds turn the machine off. Failure to do so can cause the valves to overheat and the motor will seize.
5. When finished turn the machine and the fuel tap off.
6. Release the pressure from the hose before disconnecting. Do this by squeezing the trigger, after the machine is turned off.

TO START THE ENGINE

1. Move ignition switch to the 'on' position.
2. Set the throttle to the half throttle position.
3. If the engine is cold, turn the choke lever to the 'on' position.
4. Turn the fuel tap on.
5. Crank the pull cord, until the engine starts.
6. Once the engine is running turn the choke off.

TROUBLESHOOTING

Problem	Possible solution

Do not under any circumstances attempt any repairs. Please call your local Hiredepot branch for assistance.

This operating and safety brochure is intended as a guide only for the safe operation of this equipment. It does not override license requirements nor is it a substitute for structured operating lesson. If you are unsure about any aspect of the equipment, its capabilities or the correct usage, please call our trained staff for instruction or any questions you may have regarding the safe operation of this equipment.