Operating Procedure   Chain Trencher

Guide only

Before Starting

1. Ensure there are no pipes in the area where you are to dig. DIAL 1100 BEFORE YOU DIG. Failure to locate and avoid electric cables and gas pipes could result in death.
2. If the trencher hits a solid object, release the throttle immediately and raise the bar.
3. Read and understand the Hazard Assessment sheet.

To start the Engine

1. Move ignition switch to the 'on' position.
2. Set the throttle to the half throttle position.
3. If the engine is cold, turn the choke lever to the 'on' position.
4. Turn the fuel tap on.
5. Crank the pull cord, until the engine starts.
6. Once the engine is running turn the choke off.

To stop the Engine

1. Raise the Bar out of the ground
2. Release the throttle.
3. Turn the ignition switch to the "OFF" position / depress the off button.

Operating Procedure

1. Firmly grip both handles during operation to maintain control.
2. Position the machine to work backwards.
3. Increase the throttle speed to the desired location, and slowly lower the bar until the desired depth is reached.
4. Place the handle in the operating postition

Specifications:

Trench Width: 75mm

Trench Depth: Adjustable to 600 mm

Weight: 180 kg

Dimensions:

Length   2200 mm

Width   760 mm

Height   950 mm

Transport: Trailer, Utility vehicle.

Trouble Shooting

Problem	Possible Solution
Chain has displaced from bar	Call your local Glen Iris Office for further instruction

Mandatory Personal Protective Equipment:

Dust Mask Protection

Foot Protection

Hearing

Goggles Clothing

Protective Safety

Do not under any circumstances attempt any repairs. Call your local HireDepot office.

This operating and safety brochure is intended as a guide only. It does not override license requirements nor is it suitable as an operating lesson.

If you are unsure about any aspect of the equipment, its capabilities or the correct usage, please call our trained staff for instruction or any questions you may have regarding the safe operation of this equipment.